

## Perforated Window Decal Installation

The following installation instructions are provided to ensure an easy and timely installation of your perforated window sign. Instructions will also be included with your order, and you are free to refer to this page, download a PDF of the instructions, or view the instructional video for assistance. We recommend having at least one other person assist you when installing your decal.



Clean your window, removing all dirt and grime from the surface.



Lay out your decal on the window with the backing still on and make sure it is aligned properly.



Make markings on the window with a washable marker. Be sure to double check your alignment to make sure the perforated window decal is where you want it to be.



Pull the graphic away from the window and remove the backing, exposing the black adhesive side of the decal. If the backing appears to be tearing when removing it, this may be because you are not removing all layers of the backing. When removing the backing, you should be able to see the back of the decal, which is black.



Align your decal to the markings made previously and begin to apply to the window. This will be a dry install, so do not use any water on the application surface or the adhesive side of the decal. Use a squeegee\* or flat edge when applying, starting from the center and working your way outward towards the corner of the decal.

\*Available for purchase with perforated window decal.



Once you have applied the entire perforated decal to your window, remove the excess material around the edges using a razor blade.